

IDIV

SYN NR

Appearance	off white paste
Constitution	polymeric complex
pH	5.6-6.0
Active substance	45% app.
Character	anionic

Method of use

SYN NR is a retanning complex particularly suitable for soft leather. The process using **SYN NR** is short and gives several advantages:

- The use of **SYN NR** allows a very simple retanning process;
- It is not necessary to use more fatliquor because skins retanned with **SYN NR** are sufficiently lubricated;
- **SYN NR** confers to the skins a very good softness, fulness and a pleasant and natural hand.

Process example for wet blue from South America

300%	water	30°C	
0.1%	IWET 69		
1%	IDOIL 140		20' drain-wash
100%	water	30°C	
1%	sodium formiate		15' pH=4.8
3%	SYN DCD		
15%	SYN NR		30'
X	dyestuff		90'
Y	formic acid		20' pH=3.7-3.8 then drain-wash
	a.s.o.		

edition 07/2001

The information given herein is, to the best of our knowledge true and accurate. But it is given as a guidance only and is not to be taken as a warranty of results.